


SET UP INSTRUCTIONS

1. The location chosen for use of this unit must be a relatively flat, smooth surface (wood floor, concrete, pavement or grass). Make sure you do not set up on gravel, rocks or other objects. Keep free of overhead obstructions. **Use the tarp provided, underneath the inflatable to reduce the risk of damage to the unit.**
2. The blower should be no further than 25-50 ft. from a 110 volt, 20 amp dedicated grounded electrical outlet. Extension cord are not recommended, but if you must use one, use a 12 gauge or heavier extension cord.
3. You should have at least 5 foot clearance around the unit when inflated.
4. **The unit should be anchored. Stakes have been provided for outdoor use.**
5. Roll the inflatable out and lay flat on the ground.
6. Attach the longest of the two sleeves to the blower and tie up tightly with the rope.
(Some of the smaller units may not have this)
7. Tie up the other sleeve tightly with rope, so that no air is escaping. However, it is not unusual to hear a hissing sound of air escaping. It can leak from seams & tie-off areas.
8. Switch on the blower and the inflatable will inflate. **Please note that the blower has to remain on continuously.**
9. Secure the inflatable by hammering stakes through the ropes attached to the triangular shaped eyelets, at the corners of the unit. Four should be sufficient.



GUIDELINES FOR INFLATABLES

- 1. Do not enter without adult supervision.**
- 2. Remove shoes, eyeglasses and sharp objects before entering.**
- 3. NO Flips!**
- 4. No wrestling or body contact.**
- 5. Do not bounce against sides or doorway.**
- 6. These games are physically challenging, play at your own risk.**
- 7. If unit begins to loose air, exit immediately.**
- 8. Jumpers must be of similar size, maximum of 4 children or 2 adults, at a time.**
- 9. Inflatable's can overturn in high winds. Unload jumpers and deflate if wind speed exceeds 25 mph.**
- 10. Blowers must be running as long as you are using the inflatable...When turned off, the moonwalk deflates.**
- 11. For your safety, do not use in the rain. inflatable's are operated with electricity.**
- 12. If it rains, deflate the jumper and move it and the blower to a dry area.**
- 13. Absolutely do not leave inflatable's in the rain whether they are in use or are not. Rain will cause mildew and you could be charged extra for cleaning.**
- 14. Under no circumstances is climbing on the exterior of the unit allowed.**
- 15. Keep inflatable's away from fire or fireworks.**
- 16. You will need a truck, suv or van to pick up any inflatable over 100 lbs. Our inflatable's can weigh from 50 lbs to 340 lbs. Larger inflatable's will not fit in trunks or back seats.**