


CHAFFERS & URNS

OPERATING INSTRUCTIONS



Chafing Dish and Urn (Using Sterno Type Heat)

1. Do not use anything but Sterno Type Fuel in the burner.
2. Never light the burner unit before putting liquid into the water pan or urn. Low flame is sufficient to maintain proper heat.
3. Do not put unit on a hot stove or open flame.
4. Stainless steel food pans can be used for cooking. They can also be placed in the oven to keep food hot.
5. Chafing dish water pans should be filled with hot tap water. Check water pan when in use to insure sufficient water is contained at all times. **DO NOT USE WITHOUT WATER**

Use of Sterno

Pry the lid off of Sterno and set the Sterno container into the heat cup. Light the Sterno and adjust the lid of the heat cup at approximately $\frac{1}{2}$ open. If Sterno will not stay lit, try stirring the Sterno with a disposable object. *One can of 4oz Sterno should last about 1 to 1 $\frac{1}{2}$ hours, one can of 8oz Sterno should last about 2 to 2 $\frac{1}{2}$ hours.*

Chafing Dish and Urn (Using Alcohol Burners)

1. Use **only alcohol** in the burner unit. Never use lighter fluid, gasoline, or kerosene.
2. Never light burner unit before putting water into the water pan or urn. Low flame is sufficient to maintain proper heat. The wick therefore, should not extend more than $\frac{1}{4}$ of an inch above the wick opening.
3. Do not put unit on a hot stove or open flame.
4. Do not overfill. Wipe burner dry before lighting.
5. Chafing dish water pans should be filled with hot tap water. Check water pan when in use to insure sufficient water is contained at all times. **Do not use without water!**
6. Chafers and urns must always contain at least 1 $\frac{1}{2}$ cups of water while in use.
7. **Before lighting**, fill urn with hot coffee or tea. Burner unit may then be turned up full and lit. Before drawing liquid from the urn, reduce the wick raiser down until only the top row of holes is visible (approximately $\frac{1}{4}$ inch of wick exposed). Leave the flame at this level as long as liquid remains in the urn. Shut off the burner when the liquid is withdrawn.

Cleaning Instructions

Before returning chafers, scrape and wash food pans. Wash chafers and urns in lukewarm water and a mild detergent. **NEVER USE HARSH ABRASIVES!**

Remember, you are renting this equipment. Be sure you are aware of the terms of your rental contract. Always return your chafers or urns clean, to avoid additional cleaning charges